


- IT Tosaerba falciatutto 53 cm.
- DE Sichel-Mulchmäher 53 cm.
- EN Grassland mower 53 cm.
- FR Tondeuse débroussaillieuse de 53 cm.
- ES Cortacésped 53 cm.
- SL Kosilnica s srpastim rezilom za travnate površine
- HR Kosilica sa srpastim nožem za travnate površine -53 cm.



Istruzioni d'uso
Bedienungsanweisung
Operating instructions
Mode d'emploi
Instrucciones de uso
Navodila za uporabo
Upute za uporabu



1	32.1400.910	24	32.1400.248
2	86.3988.200	25	34.1010.320
3	81.4645.000	26	32.1400.270
4	84.3708.000	27	32.1400.260
5	26.0005.232	28	86.1929.100
6	26.1005.200	29	81.4517.010
7	32.1005.195	30	32.1400.222
8	23.1005.256	31	27.0013.596
9	81.2594.050	32	40.1400.103
10	32.1400.920	33	32.1400.215
11	32.1400.904	34	32.1400.227
12	86.2168.000	35	84.6000.300
13	84.3812.000	36	26.0050.201
14	84.3619.000	37	34.1012.128
15	81.4548.000	38	32.1400.290
16	32.1400.151	39	86.2471.800
17	86.2494.000	40	32.1400.915
18	81.4588.000	41	32.1400.230
19	32.1400.053	42	32.1400.300
20	86.2786.100	43	32.1400.301
21	86.1998.000	44	32.1400.269
22	32.1400.906	45	84.3723.000
23	32.1400.142		